



# PHB Rework Adjustable Arm

Ref. RWB-B

### **Packing List**

The following items should be included:

Tool Arm ...... 1 unit





















#### **Features**

Ideal for working with JBC's Hot Air stations and a Preheater, especially the PHB-KA.




# **Assembly**

#### 1. Setting up the Tool Arm



Fit the tool arm onto the base and tighten the screw.

#### 2. Inserting the Adapter (JT/TE)



Slide the adapter along the hose to the end of the handle.

#### 3. Mounting the Tool



Insert the tool as far as possible.


#### 4. Place the hose in the clamp





# Height adjustment


- The RWB-B Arm allows adjustment for different heights according to your work needs through the vertical axis rule.
- Slide the tool holder to the appropriate height and secure by tightening the lower knob to guarantee stability. Make sure the upper knob is loosened before sliding the tool holder.



#### Work position adjustment

The RWB-B arm allows adjustment for different positions according to your work needs. The articulated arm covers all work areas.





### Ball joint adjustment



The ball joint for Rework Arm allows you to adjust the tool head holder position to suit your work needs.

Press the button or loosen the wheel to move the ball joint.

Both axes have a ruler to carry out the task with higher precision .

#### Tilting movement:




By holding down the button you can rotate the ball joint up or down.



The movement allows a rotation of  $-40^{\circ}$  to  $+40^{\circ}$ .

#### **Rotation movement:**



You can lock or unlock the lateral rotation mechanism by turning the fixing wheel a quarter.




The movement allows a rotation of -90° a +90°.



#### Maintenance

- Check periodically that the RWB-B is clean, especially the sliding parts and the shaft.
- Use a damp cloth when cleaning. Alcohol can only be used to clean the metal parts.
- Replace any defective or damaged parts. Use original JBC spare parts only.
- Repairs should only be performed by a JBC authorized technical service.



#### Safety




It is imperative to follow safety guidelines to prevent electric shock, injury, fire or explosions.


- Do not use the equipment for any purpose other than PCB rework. Incorrect use may cause fire.
- The temperature of accessible surfaces may remain high after the unit is turned off. Handle with care.
- Be careful with the fumes produced when soldering.
- Keep your workplace clean and tidy. Wear appropriate protection glasses and gloves when working to avoid personal harm.
- Utmost care must be taken with liquid tin waste which can cause burns.
- This appliance can be used by children over the age of eight as well as persons with reduced physical, sensory or mental capabilities or lacking experience provided that they have been given adequate supervision or instruction concerning use of the appliance and understand the hazards involved. Children must not play with the appliance.
- Maintenance must not be carried out by children unless supervised.

# **Exploded View**

**RWB-B**REWORK ADJUSTABLE ARM







Notes	
	_
	_
	_
	_
	_
	_
	_
	_
	_
	_
	_
	_




# **Specifications**

- Total weight: 12,5 kg (27.55 lb)

480 x 550 mm (18.90 x 21.65 in) - Base dimensions:

- Height: 386,5 mm (15.21 in) - Arm lenght: 444,5 mm (17.50 in)

- ESD safe connector

Complies with CE standards.

ESD protected.



#### Warranty

JBC's 2 year warranty covers this equipment against all manufacturing defects, including the replacement of defective parts and labour.

Warranty does not cover product wear or misuse. In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.

Register your warranty within 30 days of purchase in www.jbctools.com/productregistration



This product should not be thrown in the garbage.

In accordance with the European directive 2002/96/EC, electronic equipment at the end of their life must be collected and returned to an authorized recycling facility.





Manual in other languages available on our website